



Blackstone Porcelain Steel Fire Container

User Manual

Freedom Campfire Rings



Table of Contents

Introduction	3
Caution	4
Directions For Use	6
Building A Fire	7
Care and Use	8
Replacement Parts	9
Guarantee	10



Introduction

The Freedom Campfire Ring is a state of the art appliance for use as a container for campfires and back yard fires. The innovative design allows for efficient burning of wood and containment of the ashes and embers. Additionally, the production of annoying smoke in the Freedom Campfire Container is reduced to a minimum. The patented air flow design (U.S. Patent 6,962,148) makes starting and maintaining campfires easy and hassle free, and produces hot even coals for cooking if desired. With minimal care your Freedom Campfire Container will last for years allowing many happy campfires!



Caution

- ◆ **It is recommended not to carry the Campfire Container while it contains a fire.**

- ◆ **Be sure to provide adequate ventilation while using the Campfire Container and only use it outdoors.**

- ◆ **Provide protection underneath while using the Campfire Container over a wood or other flammable area.**

- ◆ **Use caution when disposing of hot embers to avoid fires or injury.**

- ◆ **Always supervise children when they are in the vicinity of a campfire container while it is in use.**

- ◆ **To avoid possible injury, do not touch any part of the container when it contains a fire.**

- ◆ **Place your Campfire Container away from dry grass and brush before lighting a fire in the container.**



Caution (continued)

- ◆ **Be sure the safety ring is installed into the container while in use. Severe burns can result from casually brushing against the container while it is hot.**

- ◆ **Avoid impacts to the main container. The porcelain glass coating could be chipped and damaged.**

- ◆ **Water can be used to clean your campfire container. However, it is recommended not to leave wet ashes in the container for extended lengths of time.**

- ◆ **Always use common sense to insure enjoyment of your Freedom Campfire Container.**

Directions for Use

The Freedom Campfire Container consists of 4 parts. These are:

The Main Container with integral Safety Ring.

The Stand.

The Ash Separator (Grate).

The Cooking grill.

To prepare your Freedom Campfire Container for use, set the stand on the ground with the “ring” portion up and the three legs in contact with the ground. Place the container into the stand so the container is seated into the ring on the stand.

Place the ash separator (grate with short legs) in the bottom of the container with the legs facing down. This will leave a small gap of about 1 inch between the bottom of the container and the ash separator grate. The cooking grill can be utilized by placed it on top of the container after a fire has been started and has burned down to the desired level.

To transport your Freedom Campfire Container, it has been designed so that the stand can nest inside the container.

When cool, remove the residual ashes from the container.

Rinse or wipe out the remaining debris if desired. Place the ash separate grate in the bottom of the container, and then place the stand in as well with the 3 legs pointing down. The grill can be placed on the top resulting in a compact unit for transport and storage.



Building a Fire

Due to the patented (patent granted) design of the Freedom Campfire Container, campfires are easy to start and maintain. This device burns wood efficiently and reduces the amount of smoke that is produced by the fire, resulting in a more pleasurable campfire experience. The following are suggestions for starting and maintaining a fire in your Campfire Container:

- Use a small amount of wadded up paper under some small pieces of wood (1/4 inch diameter) in the center of the container on the ash separator to get your fire going.
- Once a fire is burning, use pieces of wood from 1 to 3 inches in diameter for maximum efficiency. The regulated air flow helps prevent smaller wood from burning up too quickly.
- Larger diameter pieces can be used as well with a well established fire, but may not burn evenly or as efficiently.
- If a barbeque is desired, place a fair quantity of wood in the container, and then allow it to burn down to coals for a hot even bed to use for cooking. Place the grill into the top lip of the container when you are ready to cook.
- In order to maintain the efficiency of your Freedom Campfire Container, before making a new fire always remove the previous fire's ashes, and dispose of them in a safe and environmentally sensitive manner.

Care and Use of Your Porcelain Steel Container

Your Blackstone steel container is a beautiful appliance for your back yard or camping trip. Here are a few tips on the use and care of this quality fire container. When you first receive your container, it will be shiny and new. After you have made a number of fires in this device, the porcelain may have a coating of soot and ashes. This can easily be removed with water and a mild detergent such as glass cleaner. If your container has some tough spots from use that don't clean up easily, we recommend you use oven cleaner to make you Blackstone Fire Container shine like new.

Avoid scrubbing your container with harsh abrasives as this can scratch the porcelain coating which may result in corroding underlying steel. Also avoid impacts to the container as this will chip the porcelain.

With a minimum of care, your Blackstone container will look shiny and new throughout a lifetime of service.



Replacement Parts

If needed, replacement parts can be ordered at www.FreedomCampfire.com . Over time, the grate and grill may deteriorate due to the hot fires in the container, and replacements can be obtained at our web site listed above, or email to sales@FreedomCampfire.com . Additionally, you can order directly from Freedom Campfire by sending a letter to:

FCR Inc.
19445 Highridge Way
Trabuco Canyon, CA 92679.

Feel free to contact me with suggestions and concerns.
Email me at suggestions@freedomcampfire.com .



Satisfaction Guarantee and Manufactures Warrantee

Satisfaction Guarantee – Freedom Campfire Inc. is sure you will be completely satisfied with your purchase of a Freedom Campfire Container. If you are not completely satisfied with one of our quality Campfire Containers, simply return the product in the original packaging within 30 days to Freedom Campfire Rings, Inc., 19445 Highridge Way, Trabuco Canyon, CA 92679. We will cheerfully refund your full purchase price less shipping and handling. Please include your Name and address, and date purchased. Send any inquires to inquires@freedomcampfire.com .

Manufacture Warrantee – Freedom Campfire Rings warrantees our products to be free from manufacture defects. Every effort has been made to manufacture a quality product to ensure your enjoyment. If the product you received has a manufacture defect and/or fails to perform properly due to said defect, contact Freedom Campfire Rings at inquires@freedomcampfire.com to arrange for repair or replacement at our discretion.

Feel free to contact me with suggestions and concerns. Email me at:

suggestions@freedomcampfire.com .

Here's wishing you many happy campfires!





Freedom Campfire Rings, Inc

FCR, Inc
19445 Highridge Way
Trabuco Canyon, CA 92679

Phone: 949-547-4746
Fax: 949-713-2656
Email: floyd@freedomcampfire.com